



Southern Scentsations Inc

www.greatcandle.com

Clamshell Melts

Items Required:

Fragrance use 1 oz of fragrance for every pound of wax

EcoSoy Pillar/Votive/Melt wax

Clamshell or Any type Melt molds

Thermometer

**** Pour Pot for mixing wax and fragrance**

****Scale (to weigh out wax - optional for weighing fragrance)**

- 1.) Melt Wax using a Presto Pot or double boil method only do not place wax over direct heat.
- 2.) Place mixing pot on scale and zero out scale.
- 3.) Using a ladle add desired amount of melted wax to mixing pot on scale.

Example: 10 oz of wax times (x) by .09375 = the amount of fragrance oil to add to melted wax so $10 \times .09375 = .93\text{oz}$ of fragrance oil
So the final scale read should be at 10.93

- 4.) Add desired color, stir well. The more color you add the darker the candle wax will be.
- 5.) When temperature is at 160 f. pour Wax slowly into molds.
If you pour your wax too hot it will melt the clam shell.

When wax is completely cooled and set in molds you can close clamshell.

Soy Wax can be cleaned up by using soap and water, but please do not pour down sink, don't clean metal molds with water you must use heat gun to melt wax off and wipe clean careful it will be hot!

If selling melts please be sure to attach warning /caution sticker.